



SPLIT SILO SILO SYSTEM

1-888-SPECMIX


KEEP GOING. KEEP MOVING. KEEP WORKING.



Multiple Product Delivery for Maximum Efficiency

The SPEC MIX® Split Silo system is designed with two compartments to offer the contractor the versatility of multiple product delivery to a single mixer. Its unique design works perfectly on jobsites where more than one product is needed. The Split Silo houses five bulk bags of two different products in one silo. This silo system's compact design also makes it a good fit on tight jobsites. Only one mixer is required, making the contractor's equipment more efficient. With the SPEC MIX system, every raw material is factory preblended, packaged in heavy-duty bulk bags and dispensed into the Split Silo on site. There is no sand to shovel or pallets of bags to lift, break and discard. If the project requires masonry mortar, grout, concrete, shotcrete or stucco, the Split Silo system will produce the product quickly and consistently to increase profits while decreasing a contractor's labor and product liability.


**MINIMIZING LABOR. INCREASING
PRODUCTIVITY. IMPROVING JOBSITE
EFFICIENCY. GAINING QUALITY
ASSURANCE AND CONTROL. CUTTING
WASTE. OPTIMIZING WORKSPACE.
DECREASING LIABILITY. WORKING
SMARTER, NOT HARDER—THAT'S
THE OBJECTIVE!**





HIGH SETTING

LOW SETTING



SPECIFICATIONS

FOOTPRINT	8 FT. X 11 FT.
WEIGHT EMPTY	3,610 LB.
WEIGHT FULL	UP TO 30,000 LB.
SHIPPING HEIGHT	8 FT. 4 IN. COLLAPSED
JOB SITE HEIGHTS	LOW SETTING: 15 FT. 6 IN. HIGH SETTING: 16 FT. 6 IN.
FORKLIFT REQUIREMENTS	4,500 LB. 26 FT. DOUBLE STAGE LIFT (or) TELESCOPIC LIFT

FOR MORE INFORMATION

CONTACT SPEC MIX, INC. 1-888-773-2649

FOR MORE SPECIFIC INFORMATION,
VISIT US ONLINE AT WWW.SPECMIX.COM

OPERATING AND SAFETY INSTRUCTIONS



1

A DOUBLE BATCH OF MATERIAL IS MADE IN 5 MINUTES OR LESS WITHOUT STRAINING THE LABORERS OR COMPROMISING THE INTEGRITY OF THE MIX. NO ELECTRICITY OR PRESSURIZED WATER SOURCE IS NEEDED FOR THE SPLIT SILO, JUST A STANDARD MECHANICAL BATCH MIXER. THE SILO IS TRANSPORTABLE. AS THE JOB PROGRESSES, THE CREW AND SPLIT SILO MIXING STATION FOLLOW. THIS IS HOW IT WORKS:



2

STEP 1: To erect the Split Silo on site, make sure the ground is dry, level and compacted. With a 26 foot, 4,500 lb. capacity standard forklift, insert the forks of the lift into the Split Silo's fork pockets and raise the unit to the desired height. Four heights are available.



3

STEP 2: Using the double leg pins attached to the frame, secure the upper silo assembly by sliding the leg pins into position. Then secure the pins with the safety hitch pins. Next, attach the slide gate handle in its place and get ready to load your SPEC MIX product into the silo.

STEP 3: The bulk bags are easily loaded into the silo by inserting the forks through the bag's reinforced loops. Once the bag is above the silo and in position, the laborer standing on the safety platform can release the bag's double discharge chutes.



4

STEP 4: After the silo is loaded with four to five 3,000 lb. bulk bags, place the batch mixer beneath the cone under the silo's boot. If needed, trim the length of the boot to the top of the mixer. To make product, add the desired amount of water to the mixer and pull back the silo handle to dispense the amount of material needed to achieve the preferred consistency. Any size batch can be made. Let the product mix four to five minutes to ensure complete hydration of all materials for optimal workability and board life.



5

STEP 5: The Split Silo is easily relocated on site to position your mixing station as close as possible to the work, maximizing jobsite efficiency. With the silo legs pinned in the up or down position, insert the forks of the lift into the silo's fork pockets. Then, raise the silo and place the Split Silo in the preferred location. Make sure the forklift is equipped to safely transport the silo and that the new terrain is dry, level and stable. Always secure all leg pins and safety pins!

VISIT WWW.SPECMIX.COM TO VIEW SILO DEMONSTRATION VIDEO.