


## Concrete Repair and Restoration

Vertical and Overhead Deck Repair and Protection



## Masonry Repair and Restoration

Natural and Cast Stone, Concrete and Brick Terracotta



## Protective Coatings

Vertical  
Horizontal and Overhead



## Exterior Wall Systems

Direct Applied  
Reinforced Metal



# Surface Preparation

## Conpro Start

Spray, roller or brush applied, water based consolidant, used to stabilize and strengthen concrete, masonry and stone.

## Where to Use

Restore surface integrity and strengthen substrate prior to application of coating or repair materials.

## Coverage/Yield

80-150 ft.<sup>2</sup>/gal depending on porosity of treated surface. This is a single coat application

Apply a test sample to determine actual coverage.

## Packaging

1 and 5 gallon plastic pails.



## Conpro ECB *Electro-Chemical Barrier*

Brush or spray applied, water based, single component, zinc rich, anti-corrosion coating and long open time bonding primer.



## Where to Use

Protect reinforcing steel and metal embedded in concrete against corrosion

## How to Apply

Brush or spray

Apply a uniform 7 mils, wet to all exposed steel.



## Coverage/Yield

### *Reinforcing Steel*

1 gal - 900 ft. of #8 rebar.

5 gal - 4500 ft. of #8 rebar.

### *Concrete*

1 gal - 230 ft.<sup>2</sup> @ 7 mils.

5 gal - 1150 ft.<sup>2</sup> @ 7 mils.

## Packaging

1 and 5 gallon plastic pails.



# Surface Preparation

## Conpro Primer

Spray, roller or brush applied, long open time, water based bonding primer. Meets requirements of ASTM C882.

## Where to Use

Bonding primer for overlays and repair materials, to hardened concrete.

## How to Apply

Spray, roller or brush

## Coverage/Yield

150-200 ft<sup>2</sup>/gal depending on porosity of treated surface.



## Packaging

1 and 5 gallon plastic pails.



## ISR CM

Color matched repair mortar for cast and pre-cast concrete utilizing ECB Tech and ISR (Internal Stress Relief) technology. Available in 23 standard colors and custom color matching.



## Where to Use

Protective repairs to vertical and overhead surfaces that match the color of the parent concrete.

## How to Apply

Margin Trowel, red sponge float.

## Coverage/Yield

### Theoretical Yield

Yield per Pail	Repair Depth	Square Feet
0.42 cubic feet	1/2 Inch	10.08
0.42 cubic feet	1 Inch	5.04
0.42 cubic feet	1.5 Inches	3.36
0.42 cubic feet	2 Inches	2.52



## Packaging

50 lbs plastic pails.



# Concrete Repair Mortars

## Conpro Set

Trowel applied, single component, polymer-modified cementitious repair mortar with ECB-Tech corrosion Protection. **Do not add K-88 Admixture.**



## Where to Use

Structural and protective repairs to vertical, overhead and horizontal concrete.

## How to Apply

Margin Trowel, red sponge float

## Coverage/Yield

0.42 ft.<sup>3</sup>/50 lbs.

0.65 ft.<sup>3</sup> when extended with 30 lbs. of 3/8 inch aggregate



## Packaging

50 lbs. paper bag, 10 lbs. and 50 lbs. plastic pails.



## Conpro One Shot 2C

Trowel or pump applied, two component, polymer modified, Portland cement material for horizontal applications up to 1/2 inch.

### Where to Use

Resurface balconies, parking decks, industrial floors, loading docks and ramps.

### How to Apply

Finishing trowel, Pool trowel or Margin Trowel.

### Coverage/Yield

50 ft.<sup>2</sup>/50 lbs. @ 1/8 inch.

### Packaging

50 lbs. paper bags and 1-gallon K88 Admixture.



# Concrete Repair Mortars

## Gun Shot LPS

Low pressure, wet process spray applied, fiber reinforced, silica fume enhanced, repair mortar with ECB-Tech corrosion protections.  
**Do not add K-88 Admixture.**

## Where to Use

High production vertical and overhead concrete repairs. Wet process minimizes dust and rebound.



## How to Apply

Trowel or spray applied.




## Coverage/Yield

0.41 ft<sup>3</sup>/50 lbs.

## Packaging

50 lb paper bag.



## ISR V/O

Portland cement based concrete repair material with ECB-Tech corrosion protection. ISR technology (Internal Stress Relief).

**Do not add K-88 Admixture.**



## Where to Use

Protective repairs to vertical and overhead concrete. Single component, low shrinkage.

## How to Apply

Trowel

## Coverage/Yield

0.41 ft<sup>3</sup>/50 lb bags - 9ft<sup>2</sup> @ 1/2 inch.



## Packaging

50 lb paper bag



# Concrete Repair Mortars

## ISR Ag

Durable, crack resistant repair material utilizing ISR (Internal Stress Relief) technology with ECB-Tech corrosion protection. **Do not add K-88 Admixture.**

## Where to Use

Pour, pump or hand patch material for parking and plaza decks, balconies and marine structures.



## How to Apply

Trowel in horizontal, form & pour/pump for vertical/overhead.



## Coverage/Yield

0.49 ft.<sup>3</sup>/60 lb. bag

## Packaging

60 lb paper bags.



## Matrix

Trowel applied, cementitious repair mortar, formulated to be compatible with the color and physical properties of parent material. Available in 23 standard colors and custom color matching.



## Where to Use

Repair and reconstruct natural and cast stone, terracotta, and brick.



## How to Apply

Margin trowel

## Packaging

5 gallon plastic pails - 50 lbs.

## Coverage/Yield (Theoretical Yield)

Yield per Pail	Repair Depth	Square Feet
0.5 cubic feet	1/2 Inch	12.00
0.5 cubic feet	1 Inch	6.00
0.5 cubic feet	1.5 Inches	4.00
0.5 cubic feet	2 Inches	3.00



# Masonry Repair and Restoration

## Matrix Superfine

Trowel applied, composite repair mortar, formulated to be compatible with the color and physical properties of parent material. Available in 23 standard colors and custom color matching.

### Where to Use

Repair and reconstruct natural and cast stone, terracotta, and brick when a very smooth finish is required.

### How to Apply


Margin Trowel

### Packaging

5 gallon plastic pails – 50 lbs.

### Coverage/Yield (Theoretical Yield)

Yield per Pail	Repair Depth	Square Feet
0.5 cubic feet	1/2 Inch	12.00
0.5 cubic feet	1 Inch	6.00
0.5 cubic feet	1.5 Inches	4.00
0.5 cubic feet	2 Inches	3.00



## Matrix VE

Pour applied, viscosity enhanced cementitious repair mortar, formulated to be compatible with the color and physical properties of parent materials.



## Where to Use

Form repairs and place in molds for natural and cast stone, terracotta, and brick.



## How to Apply


Form and Pour/Place

## Packaging

5 gallon plastic pails – 50 lbs.

## Coverage/Yield (Theoretical Yield)

Yield per Pail	Repair Depth	Square Feet
0.5 cubic feet	1/2 Inch	12.00
0.5 cubic feet	1 Inch	6.00
0.5 cubic feet	1.5 Inches	4.50
0.5 cubic feet	2 Inches	3.00



# Masonry Repair and Restoration

## Matrix TR

Brush applied, polymer modified, cementitious repair mortar for thin repairs to natural and cast stone. Available in 23 standard colors and custom color matching.

## Where to Use

Thin, protective repair to brownstone, sandstone, limestone, cast stone, terracotta and concrete.

## How to Apply

Brush or Red sponge float

## Coverage

10 lb. kit – 20 ft<sup>2</sup> @ 1/16 inch.

## Packaging

10 lb. kit contains 8.36 lbs of powder and 2.1 lbs of K88 in plastic pails.



## RePoint

Meets the requirements of ASTM C387 and C270 for the respective compressive strength of Type O and Type N mortars. Available in 23 standard colors and custom color matching.

## Where to Use

Available in both Type O and Type N formulations and can be used anywhere these types are specified.

## How to Apply

Repointing Tool

## Packaging

5 gallon plastic pail, 50 lbs. paper bag

## Coverage/Yield (Theoretical Yield)

<b>1 Bag/Pail (50 lb)</b>	<b>Joint Width</b>	<b>Joint Depth</b>	<b>Lineal Feet</b>
1 Bag/Pail (50 lb)	1/4 inch	5/8 inch	442
1 Bag/Pail (50 lb)	3/8 inch	3/4 inch	245
1 Bag/Pail (50 lb)	1/2 inch	1 inch	138



# Masonry Repair and Restoration

## Injection Grout

Cementitious crack injection grout/adhesive for the repair of hairline to  $\frac{3}{4}$  inch cracks in masonry and concrete. Available in 14 standard colors.

## Where to Use

Repair and reconstruct brownstone, sandstone, limestone, cast stone, concrete, marble, granite, terracotta and brick.



## How to Apply

Injection syringe, modified bulk guns, or low-pressure grout pump.



## Coverage/Yield

0.25 ft<sup>3</sup>/30 lb pail.

## Packaging

30 lb plastic pail.



## Terracotta Repair

The repair of terracotta follows the same principles of proper stone and concrete repair. Achieving an aesthetically pleasing result requires the right materials, tools and excellent craftsmanship. Terracotta repair can be categorized as shallow repairs (glaze spall  $<1/4"$ ) or deep repairs (bisque spall  $1/2" +$ ) below. The method of repair can vary slightly depending on the category.




### Bisque Spall Repair ( $1/2" +$ )



**STEP 1** – Match the primary color of the terracotta using Matrix fobs. Make three 'pucks', one the color closest to the terracotta, one a shade darker and one a shade lighter. The finish must be troweled smooth.



**STEP 3** – Apply the color matched Matrix to the repair zone. Over build and allow to 'set' until thumbprint.



**STEP 2** – Cut out the damaged area (minimum  $1/2$  inch deep) so that the area to be repaired will be a geometric shape. In this case foam insulation was used to prevent filling the cavity with the repair mortar.



**STEP 4** – Shave the Matrix with a miter rod or edge of trowel to final form. Finish the repair to match the existing surface of terra cotta. In this case, the repair was finished smooth.

# Masonry Repair and Restoration



**STEP 5 Optional** – If Matrix material was color matched to parent terracotta, skip to **STEP 6**. If not, apply Terra-Color paint, two 'pucks'. Brushes and sandpaper.

**STEP 6** – Apply Terra-Color matched to the accent color(s) and same pattern as to the parent stone. Allow to dry for a minimum of 12 hours. Apply Terracotta Finish to the repaired area either gloss or Matte to match the finish.

## Glazed Spall Repairs (<1/4")

Glazed spall repairs should be attempted on damaged terracotta spalls of  $\frac{1}{4}$ " or less. First inspect the glaze near the perimeter of the spall. Be sure it is still sound (well bonded) and free of Biological growth. To minimize feathering, create a square shoulder for the spalled area. Following the instructions on the data sheet, apply Matrix TR (in  $\frac{1}{16}$ " lifts if necessary) to repair the spall. The Matrix TR should be textured during finishing to match the existing terra cotta texture. The Matrix TR can be color matched to the existing terra cotta if desired. The repaired spall should be coated with Terra-Color and/or Terracotta Finish as described in Step 5 and 6 above.



### Plastermix

Trowel, sponge float, or spray applied, Portland cement finish coating for concrete.



### Where to Use

Fill voids and provide a uniform finish to concrete. Apply before application of a coating for a uniform appearance.

### How to Apply

Plastering trowel, Pool trowel, Green sponge float

### Coverage/Yield

100 ft.<sup>2</sup>/50lbs. @ 1/16th inch.

### Packaging

50 lbs. paper bag



# Protective Coatings

## Conpro Lastic

Roller, spray (smooth) or brush applied, waterproof, elastomeric, crack bridging, anti-carbonation.

### Where to Use

Protect vertical concrete, block, brick, stucco and EIFS from water and contaminant entry. Will bridge minor cracking.



### How to Apply

Roller, spray (smooth) or brush

### Coverage/Yield

100 ft.<sup>2</sup>/gal. @ 15 mils. Wet for smooth surfaces.

50-75 ft.<sup>2</sup>/gal. @ 15 mils. Wet for split block or rough surfaces.



### Packaging

5 gallon plastic pails



## Color Coat

Roller, spray (smooth) or brush applied, 100% acrylic waterproof coating.

## Where to Use

Enhance appearance and protect vertical and overhead concrete block, stucco, brick and synthetic stucco.

## How to Apply

Roller, spray (smooth) or brush



## Coverage/Yield

200 ft.<sup>2</sup>/gal. @ 8 mils. wet.

120 ft.<sup>2</sup>/gal. @ 8 mils. wet. For split block or rough surfaces.

## Packaging

5 gallon plastic pail.



# Protective Coatings

## Super Color Stain

Roller, spray or brush applied; water-based opaque acrylic stain.

## Where to Use

Enhance appearance and protect concrete, CMU, stucco, brick, and as a washable finish for Elastideck.

## How to Apply

Roller, spray or brush


## Coverage/Yield

250 ft.<sup>2</sup>/gal. @ 6 mils. wet.

150 ft.<sup>2</sup>/gal. @ 6 mils. wet. for split block or rough surfaces.

## Packaging

5 gallon plastic pail. 45 lbs. per pail.



## M3P Overcoat

Roller or brush applied, hybrid mineral silicate paint.

### Where to Use

M3P Overcoat is used over properly prepared silicone, elastomeric and conventional masonry coatings. M3P Overcoat can also be applied to sound uncoated masonry surfaces in addition to coated surfaces.

### How to Apply

Roller or brush

### Coverage/Yield

170-300 ft.2/gal.

100-180 ft.2/gal. for split block or rough surfaces.

### Packaging

5 gallon plastic pail. 45 lbs. per pail.



# Protective Coatings

## M3P

Long term protection and enhanced aesthetics of concrete, masonry and stone. Opaque and semi-transparent finishes are obtainable.

## Where to Use

Used when objective is to blend substrate color variation to be more uniform.

## How to Apply

Brush or roller applied, mineral silicate coating. Refer to data bulletin for more information.

## Coverage/Yield

Coverage rates vary considerably from substrate to substrate for all potassium silicates coatings due to surface texture and absorption rates of the masonry being coated. Apply a mockup to determine coverage rates for specific project.

170-300 ft.<sup>2</sup>/gal.

## Packaging

5 gallon plastic pail. 45 lbs. per pail.



# Protective Coatings - Diluent

## M3P-X

Mineral Silicate Diluent

### Where to Use

Clear penetrating mineral silicate diluent used for creating semi-transparent finishes with M3P.

### How to Apply

Refer to data bulletin for information.

### Coverage/Yield

Coverage rates vary considerably from substrate to substrate for all potassium silicates coatings due to surface texture and absorption rates of the masonry being coated. Apply a mockup to determine coverage rates for specific project.

M3P - X 150-300 ft<sup>2</sup>./gal.

### Packaging

5 gallon plastic pail. 45 lbs. per pail.



## Protective Coatings - Clear

### Shield MX

Spray, roller or brush applied, penetrating aqueous silane/siloxane water repellent.



### Where to Use

Vertical and horizontal concrete, concrete block, concrete pavers, natural stone, stucco and brick.



### How to Apply

Low pressure spray, roller or brush.

### Coverage

Coverage will vary depending upon porosity of substrate.

Concrete 125-175 ft.<sup>2</sup>/gal.

Concrete Block 40-150 ft.<sup>2</sup>/gal.

Brick 100-175 ft.<sup>2</sup>/gal.

### Packaging

1, 5 and 54-gallon plastic pails.



## Protective Coatings - Horizontal

### Elastideck

Spray, roller or squeegee applied, acrylic modified, cementitious, flexible, waterproof membrane. Available in 14 standard colors.

### Where to Use

Decorative coating for balconies, walkways, driveways, planters and parapets.

### How to Apply

Spray, roller or squeegee.

### Coverage/Yield

80 ft.<sup>2</sup>/25 lbs. kit @ 50 mils.

### Packaging

3.5 gallon plastic pails. 12.5 lbs. of powder and 1-1/4 gallons of admix.



# Exterior Wall Systems

## Structural Skin

Trowel or spray applied, fiber reinforced, cement based structural coating. Refer to Conproco Exterior Wall Systems. Add 1 quart of K88 Admixture per 50 lbs. bag for curing.

## Where to Use

Base coating for exterior wall systems over block, concrete, brick, exterior sheathing and plywood.

## How to Apply

Plastering Trowel, Pool Trowel

## Coverage/Yield

45 ft.<sup>2</sup>/50 lbs. @ 1/8 inch.

## Packaging

50 lbs. paper bags.



## Conpro One Coat

Trowel or spray applied, cement based, fiber reinforced, polymer enhanced base coat. **Do not add K-88 Admixture.**

## Where to Use

Combine scratch and brown coats of traditional stucco systems into one coat stucco base and finish.

## How to Apply


Plastering trowel, Pool trowel and Margin trowel

## Coverage/Yield

16 ft.<sup>2</sup>/50 lbs. @ 3/8 inch.

## Packaging

50 lbs. paper bags.



# Exterior Wall Systems

## Conpro Stucco

Trowel or spray applied, traditional Portland cement stucco. Refer to Conproco Exterior Wall Systems. Use 1 quart of K-88 or Color K-88 per 50 lb. bag.



## Where to Use

For a natural appearing, decorative texture coating on concrete, masonry and curtain wall construction.

## How to Apply

Plastering trowel, Pool trowel

## Coverage/Yield

50 ft.<sup>2</sup>/50 lbs. @ 1/8 inch.



## Packaging

50 lbs. paper bag.



# SPRAY AND PUMPING EQUIPMENT

## CEMENT BASED MATERIALS

	Hopper Gun	Rotor/Stator Size 3	Peristaltic (Carousel)	Rotor/Rtator Size 6	Piston
Gun Shot LPS	-	✓	✓	✓	-
Plastermix	✓	✓	✓	✓	-
ISR Ag	-	-	-	-	✓
Structural Skin®	-	✓	✓	✓	-
Conpro One Coat	-	✓	✓	✓	-
Conpro Stucco	✓	✓	✓	✓	-
Foundation Coat	-	✓	✓	✓	-
Conpro Super Seal	✓	✓	✓	✓	-

Manufacturer	Type	Telephone	Web Address
Marshalltown	Hopper Guns	800.888.0127	<a href="http://www.marshalltown.com">www.marshalltown.com</a>
Hy-Flex	Rotor/Stator	866.849.6246	<a href="http://www.hyflexcorp.com">www.hyflexcorp.com</a>
Quikspray	Peristaltic	419.732.2611	<a href="http://www.quikspray.com">www.quikspray.com</a>
ChemGrout	Rotor/Stator & Piston	708.354.7112	<a href="http://www.chemgrout.com">www.chemgrout.com</a>
Reed	Gunite/Shotcrete	888.779.7333	<a href="http://www.reedmfg.com">www.reedmfg.com</a>

The gallons per minute volume of a rotor/stator pump is determined by the pump size (i.e. size 6 has a larger capacity than size 3).

The pressure capacity of a pump is determined by the number of stages. Thicker materials and longer distances require higher pressure.

# SPRAY AND PUMPING EQUIPMENT

## LIQUIDS AND COATINGS

	Low Pressure	Airless-tip size 0.011-0.021	Airless-tip size 0.019-0.021	Airless-tip size 0.041-0.047
Conpro Start	✓	✓	-	-
ECB	-	-	-	✓
Conpro Primer	✓	✓	-	-
Conpro Shield MX	✓	-	-	-
M3P	-	-	-	✓
M3P Overcoat	-	-	-	✓
Conpro Lastic (Smooth)	-	-	-	✓
Color Coat (Smooth)	-	-	✓	-
Super Color Stain	-	-	-	✓

Manufacturer	Type	Telephone	Web Address
R.E. Chapin MFG	Low pressure spray	800.950.4458	<a href="http://www.chapinmfg.com">www.chapinmfg.com</a>
Titan Tool Inc.	Airless sprayers	800.526.5362	<a href="http://www.titantool.com">www.titantool.com</a>
Binks	Airless sprayers	888.992.4657	<a href="http://www.binks.com">www.binks.com</a>
Graco Inc.	Airless sprayers	612.623.6000	<a href="http://www.graco.com">www.graco.com</a>

The capacity of airless spray equipment is determined by the tip size. Given the proper tip size the manufacturer of the equipment will be able to recommend specific equipment.

## TROWEL AND FLOAT GUIDE

	Plastering Trowel	Finishing Trowel	Pool Trowel	Margin Trowel	Floats
Conpro Set	-	-	-	✓	Red Sponge
ISR V/O	-	-	-	✓	Red Sponge
ISR CM	-	-	-	✓	Screed
Plastermix	✓	-	✓	✓	Red Sponge
Gun Shot LPS	✓	-	✓	✓	Red Sponge
ISR Ag	-	✓	✓	✓	Mag Float/Broom
Conpro One Shot 2C	-	✓	✓	✓	Mag Float/Broom
Elastideck	-	✓	✓	-	-
Matrix	-	-	-	✓	Screed
Matrix Superfine	-	-	-	✓	Screed
Matrix TR	✓	-	-	✓	Red Sponge
Structural Skin	✓	✓	✓	✓	Red Sponge
Conpro One Coat	✓	✓	✓	✓	Red Sponge
Conpro Stucco	✓	-	✓	-	Red Sponge
Foundation Coat	✓	✓	✓	✓	Red Sponge

***The above chart provides choices for recommended application and finishing tools.***

Plastering Trowels	11 x 4-1/2 to 14 x 4-1/2 ins.	Size determined by area to be finished
Finishing Trowels	12 x 4 to 20 x 5 ins.	Size determined by area to be finished
Pool Trowel	14 x 3 to 14 x 4 ins.	Easy to use for those less skilled
Margin Trowel	5 x 1-1/2 to 8 x 4 ins.	Use to place small repairs
Red Sponge	Various	Use for tight, flat finishes

**PRODUCT CURING TIME GUIDE** - The curing times are provided to give guidance only.

Product	Minimum Temperature	Minimum To 55°	55° - 70°	70°F and Above	Minimum Time To Coat*
Conpro Start	40°F	24 Hours	18 Hours	12 Hours	24 Hours
ECB	40°F	8 Hours	1 Hours	30 Minutes	Dry to Touch
Conpro Primer	40°F	8 Hours	1 Hours	30 Minutes	Orange Color
Conpro Set	40°F	12 Hours	4 Hours	2 Hours	3 to 5 Days
ISR V/O	40°F	24 Hours	18 Hours	12 Hours	3 to 5 Days
ISR Ag	40°F	24 Hours	18 Hours	12 Hours	3 to 5 Days
ISR CM	40°F	24 Hours	18 Hours	12 Hours	3 to 5 Days
Plastermix with K-88	40°F	12 Hours	4 Hours	2 Hours	3 to 5 Days
Gun Shot LPS	40°F	12 Hours	8 Hours	4 Hours	3 to 5 Days
Conpro One Shot 2C	40°F	24 Hours	12 Hours	6 Hours	3 to 5 Days
Conpro Shield MX	40°F	24 Hours	18 Hours	12 Hours	Dry to Touch
M3P	45°F	24 Hours	18 Hours	12 Hours	Dry to Touch
M3P Overcoat	45°F	24 Hours	18 Hours	12 Hours	Dry to Touch
Conpro Lastic	45°F	24 Hours	18 Hours	12 Hours	Dry to Touch
Color Coat	45°F	24 Hours	18 Hours	12 Hours	Dry to Touch
Super Color Stain	45°F	24 Hours	18 Hours	12 Hours	Dry to Touch
Terra Color	45°F	24 Hours	18 Hours	12 Hours	Dry to Touch
Elastideck	45°F	24 Hours	18 Hours	12 Hours	Dry to Touch

**CURING TIME** - THE MINIMUM TIME A PRODUCT MUST BE PROTECTED FROM RAIN OR PHYSICAL CONTACT.

**\*MINIMUM TIME TO COAT** - THE MINIMUM TIME A PRODUCT MUST CURE BEFORE APPLYING AN ACRYLIC COATING OR A SECOND APPLICATION OF THE SAME COATING. THIS IS BASED ON CONPROCO PRODUCTS.

## PRODUCT CURING TIME GUIDE - The curing times are provided to give guidance only.

Product	Minimum Temperature	Minimum To 55°	55° - 70°F	70°F and Above	Minimum Time To Coat*
Matrix	40°F	24 Hours	18 Hours	12 Hours	3 to 5 Days
Matrix Superfine	40°F	24 Hours	18 Hours	12 Hours	3 to 5 Days
Matrix VE	40°F	24 Hours	18 Hours	12 Hours	3 to 5 Days
Matrix TR	50°F	24 Hours	18 Hours	12 Hours	24 Hours
RePoint	50°F	24 Hours	18 Hours	12 Hours	3 to 5 Days
RePoint VE	50°F	24 Hours	18 Hours	12 Hours	3 to 5 Days
Terracotta Finish	50°F	24 Hours	12 Hours	6 Hours	Dry to Touch
Structural Skin	40°F	12 Hours	3 Hours	2 Hours	24 Hours
Conpro One Coat	40°F	24 Hours	18 Hours	12 Hours	3 to 5 Days
Conpro Stucco	40°F	12 Hours	8 Hours	4 Hours	24 Hours
Foundation Coat	40°F	12 Hours	3 Hours	2 Hours	24 Hours
Conpro Super Seal	40°F	12 Hours	6 Hours	2 Hours	Dry to Touch

**CURING TIME** - THE MINIMUM TIME A PRODUCT MUST BE PROTECTED FROM RAIN OR PHYSICAL CONTACT.

**\*MINIMUM TIME TO COAT** - THE MINIMUM TIME A PRODUCT MUST CURE BEFORE APPLYING AN ACRYLIC COATING OR A SECOND APPLICATION OF THE SAME COATING. THIS IS BASED ON CONPROCO PRODUCTS.

# ECB Technical Data


## DEFINITION OF CORROSION ON REINFORCING STEEL

### PROBLEM

The electrochemical deterioration of metal due to the reaction with its environment.


### SOLUTION

ECB combats corrosion in using a unique, three-tiered system.




### BARRIER

ECB forms an impervious membrane to protect rebar from water, chlorides, oxygen, and carbon dioxide. This function is similar to epoxy coatings.




### SACRIFICIAL

ECB provides passive cathodic protection which, if needed, donates electrons (sacrificial anode) to stop corrosion. This function is similar to zinc-rich primers.



### CHEMICAL

ECB provides chemical protection that works concurrently with the passive cathodic protection. Ions produced during the sacrificial process migrate towards an establishing cathode. At the cathode they react and deposit a protective layer which obstructs further cathodic reactions, arresting corrosion. This function is similar to migratory inhibitors.



For more information on ECB request the full Technical Bulletin. Email customer support at [orders@conproco.com](mailto:orders@conproco.com)